

TECHNICAL DATA SHEET

HOBART S3 HRO SRC HI CI

Safety shoes

Article NO: G3216

Upper: cow leather

Sole: PU/ rubber

Description: full-leather ankle shoes with laminate toe cap, flexible kevlar insole, water resistant

Size: 36 - 48



Full-leather ankle shoes with laminate toe cap, flexible kevlar insole, water resistant. Black and red colour. Flexible kevlar insole protects the entire area of the foot. No metal parts. This safety ankle shoes are suitable for use at building and heavy machinery.

Type and degree of protection:

Category	EN ISO 20345
Antistatic properties	x
Absorption of energy in the heel area	x
Sole with pattern- oil resistance	x
Water resistance	x
Puncture resistance (kevlar insole)	x
Laminate safety toecap for toe protection	x
Without metal parts	x
Slip resistant ceramic tile floor with SLS and on steel floor with glycerol (SRC)	x
HI - insulation of the bottom of the shoe against heat	x
CI - insulation of the bottom of the shoe against the cold	x





This personal protective equipment is in conformity with this harmonized European Standard:

EN ISO 20345:2011 : Personal protective equipment - safety shoes.

Slip resistance on ceramic tile floor with SLS and on steel floor with glycerol (SRC mark).

Certified by notified body no. 0120 (SGS United Kingdom Limited) dated 9th August 2019, Certificate number GB 19/963814.

Pairs in carton:	10
Carton weight:	20,80 kg
Carton size:	0,123 m³

The shoes have to be perfect as for form and size, because they have rigid parts. The right size has to be found by measuring practically and carefully the shoes. The closing system has to be used correctly. The laces have to be tightened well without leaving too long free tops. The shoes have to be cleaned and treated with right, specific products, following the instructions for use. Do not keep footwear near heatings when not used and let them dry in a windy or room temperature. Before wearing and when cleaned, the shoes have to be controlled in order to find out visible defects existing, like closing system function, outsole profile's water, possible damages, etc. To define the right type of footwear to wear in every environment, the possible dangers and the place/ environment have to be included (e.g. construction industry, high temperatures, etc.). The shoes have to be stored correctly, keeping them in the proper packing.
